



Drill pilot holes, 1/16" dia bit.  
Layout holes 1/8" from either edge.  
10 1/4" on center of hole in blade.

**NOTE:**  
Determine if you want a LEFT or  
RIGHT hand knife  
before drilling 1/16" pilot holes.

KenCraft Co Inc 821 N Westwood Ave Toledo OH 43607  
Phone 419-536-0333 Email [hardwoods@kencraftcompany.com](mailto:hardwoods@kencraftcompany.com)  
[www.kencraftcompany.com](http://www.kencraftcompany.com)